

PERF	INSP

4.0 ACCOMPLISHMENT INSTRUCTIONS

4.1 TCAS PROCESSOR REMOVAL/INSTALLATION

1. Obtain TCAS Processor part number 7517900-10020 from spares.
2. Remove the existing TCAS Processor, part number 7517900-10012 per the 737-300/400/500 Aircraft Maintenance Manual 34-45-11/401.
3. Install the new part number TCAS Processor part number 7517900-10020 per the 737-300/400/500 Aircraft Maintenance Manual 34-45-11/401.

4.2 TCAS SELF TEST

1. Close the following circuit breaker:

<u>Circuit Breaker</u>	<u>Panel</u>
TCAS	P18-1
2. Push and release the **PUSH TO TEST** button on the front of the TCAS Computer; reference Figure 1. Verify the following sequence:
 - a) All TCAS computer unit front panel annunciators come on for a 3-second lamp test.
 - b) If the TCAS is operational, the **TCAS PASS** green annunciator comes on for a 10-second display period and then goes off.
 - c) If the TCAS is not operational, one or more of the red fault annunciators comes on for a 10-second display period.

4.3 TCAS OPERATIONAL TEST

1. Ensure the following systems are on and operational:
 - a) Air Data System
 - b) Air Traffic Control System
 - c) Electronic Flight Instrument System
 - d) Flight Interphone System
 - e) Inertial Reference System
 - f) Low Range Radio Altimeter
2. Align all the IRS systems.
3. Ensure the all of the IRS systems are in the **NAV** mode.
4. On the TCAS/ATC Control Panel perform and verify the following:
 - a) Place the mode select switch to the **TA/RA** position.
5. On both EFIS control panels perform the following:
 - a) Set the display mode switch to **MAP**.
 - b) Depress the **TFC** button.
 - c) Make sure the EHSI shows **TFC** on the display.
6. On the TCAS/ATC Control Panel perform and verify the following:
 - a) Place the **XPNDR** selector switch to the **1** position.
 - b) The **XPNDR FAIL** light is not illuminated.
 - c) Rotate the mode selector knob to the **STBY** position.
 - d) Make sure the EHSI shows the **TCAS OFF** indication.