

PERF	INSP

5.0 MODIFICATION COMPLETION

1. Reduce the air data test set to field elevation and disconnect it from the airplane per the 737-300/400/500 Aircraft Maintenance Manual 34-12-01/501.
2. Disconnect the radio altimeter test set from both radio altimeters per the 737-300/400/500 Aircraft Maintenance Manual 34-48-02/201.
3. Close the following circuit breaker:

<u>Circuit Breaker</u>	<u>Panel</u>
LND GR AIR/GND RLY & LTS	P6-3
4. Remove the ground locks from the nose and main landing gear per the 737-300/400/500 Aircraft Maintenance Manual 32-00-01/201.
5. Return all airplane systems to their normal ground condition.
6. Remove power from the airplane per the 737-300/400/500 Aircraft Maintenance Manual 24-22-00/201.
7. Remove the electrical ground from the airplane per the 737-300/400/500 Aircraft Maintenance Manual 20-40-11/201.